

QA Testing Checklist

Everything to check in the mobile app, the client panel and the admin panel — with a short daily run at the front and the full release run behind it.

For: manual testing, no coding needed

Companion to: *QA Onboarding & Study Guide* (how to test, how to write a bug ticket)

194 checks · version 1 · August 2026

Contents

1	How to use this list	page 3
	Daily run vs release run · what the star means · what to do when something fails	
2	Where to test	page 4
	Environments · browsers · phones · the sensor kit	
3	The daily check	page 5
	32 items · about 50 minutes · run this every morning	
4	Mobile app — full checklist	M-01 → M-09
	Login · setup · sensors · calibration · recording · sync · history · offline · settings	
5	Client panel — full checklist	W-01 → W-92
	Login · home · measurements · assessments · workers · team · work library · settings	
6	Admin panel — full checklist	A-01 → A-09
	Organisations · users · devices · firmware	
7	Cross-cutting checks	X-01 → X-13
	Languages · roles · screen sizes · browsers · bad network · empty states	
8	Known and already reported — do not file these	last page
	Things that look like bugs but aren't, or are already on the list	

1 · How to use this list

Two runs, one list. Nothing here needs code — it's all clicking, tapping and looking carefully.

The daily run — every morning, about 50 minutes

Section 3. It answers one question: **is anything obviously broken right now?** Log in, open the main screens, record a short session, check the data arrives. It is not meant to find subtle bugs — it's meant to catch a broken build before the whole team wastes a day on it. If everything passes, say so in the team chat in one line and move on to your other work.

You don't need to record 32 passes. **Only report what fails.**

The release run — before every release

Sections 4 to 7, all of it. Takes one to two days. This is the full sweep: every screen, every field, every error message, plus the cross-cutting pass in section 7. Here you *do* keep a record of what passed and what failed, so we know the release was actually covered.

What the star means

★ in the full list = this item is also part of the daily run. Same check, listed once, so the two runs can never drift apart.

Every item is written the same way

ID · what you do — what should happen.

M-16 ★ Assign a sensor to a limb — it connects, shows its serial number and a battery percentage

If what happens is different from what's written after the dash, that's a bug. Some items are deliberately open ("check what happens when...") — those are where you use your judgement and ask if you're unsure.

When something fails

Write a bug ticket the way the *QA Onboarding & Study Guide* describes — title, steps, what happened, what you expected, screenshot, environment, severity. **Put the check ID in the ticket** (for example "fails M-16"), so we can trace it back here.

Before you file anything, read section 8.

Some things in the apps are unfinished on purpose or already reported. Filing them again wastes your time and the developers'.

Keep this list alive.

Every real bug you find that isn't covered by an item here should become a new item. That's how the list grows — it should be noticeably longer in six months than it is today. Tell us when you add one so the IDs stay unique.

2 · Where to test

Get these set up and written down before your first run. Ask the team for the accounts.

Environments

What	Where	Use it for
Test (web)	<code>dev.cloud.wergonic.com</code>	Everything. This is your home. Break it freely.
Production (web)	<code>cloud.wergonic.com</code>	Look only. A quick check after a release that it loads and login works. Never create test data here.
Mobile app	The test build the team gives you	It points at the test backend. Confirm which build you have before reporting anything.
Admin panel	Runs locally only, for now	See the note below — check with the team before testing it.

Two things to confirm on day one.

The environment names are being reorganised, so ask which URL is the current test environment before you start. And the admin panel currently points at a backend running on the developer's own machine — it can't be tested on a normal URL yet. Ask before you spend time on section 6.

Accounts you need

One of each role, on the test environment, so you can check that people only see what they should:

- **Org admin** — sees everything in one organisation, including Team
- **Ergonomist** — records and analyses, but no Team page
- **Worker** — mobile app only; must be refused on the web
- **Superadmin** — for the admin panel
- A user who belongs to **two organisations**, to test switching

Browsers and screens (web)

Chrome is your everyday browser. For the release run, also go through the main flows in Edge, Safari and Firefox. Screen sizes to check: a 1366-wide laptop, a 1920 desktop, and a tablet width. If something only breaks on one of them, say which one in the ticket.

Phones (mobile)

At least one Android and one iPhone, and ideally one older, slower Android — that's where recording problems show up first. Always write the phone model and OS version in the ticket.

The sensor kit

Some checks need the physical sensors and the workwear — they're marked **needs the kit** in section 4. You can't do them from your desk. If the kit isn't always available to you, do the kit part of the daily run at least twice a week, and always before a release.

3 · The daily check

32 items, about 50 minutes. Two halves: the desk half needs nothing but a laptop and a phone; the kit half needs the sensors. Run it on the test environment, every morning.

Part A · At your desk ~20 minutes · no hardware needed

- ☐ W-01 The login page loads, nothing looks broken
- ☐ W-02 Log in with email and password
- ☐ W-12 Home page loads and shows numbers, not errors or empty cards
- ☐ W-16 Measurements list loads and shows rows
- ☐ W-18 Search a worker's name — the list filters
- ☐ W-28 Open a finished measurement — the charts draw, no blank page
- ☐ W-52 Assessments list loads
- ☐ W-56 Open one completed assessment — the score and colours show
- ☐ W-64 Workers list loads
- ☐ W-71 Team page loads (as an org admin)
- ☐ W-77 Work library opens and the factory tree expands
- ☐ W-88 Notification bell opens and shows the list
- ☐ W-85 Switch the language and back — text changes, nothing overflows
- ☐ W-11 Log out — you land on the login page and can't go back in with the back button
- ☐ X-12 No red errors in the browser console on any page you opened
- ☐ M-01 Mobile app opens past the splash screen without crashing
- ☐ M-02 Log in on mobile
- ☐ M-58 Session history loads and shows past sessions
- ☐ M-60 Open a past session report — the charts draw
- ☐ M-64 Turn wifi and data off — the offline banner appears
- ☐ M-70 Change one setting, force-close the app, reopen — the setting stuck

Part B · With the sensor kit ~30 minutes · twice a week minimum, and before every release

- ☐ M-15 Scan finds the sensors
- ☐ M-16 Pair a sensor to a limb — it connects and shows a serial number
- ☐ M-21 Battery percentage shows for each connected sensor
- ☐ M-24 Calibration runs through every connected limb and finishes
- ☐ M-37 Start recording — the timer counts up
- ☐ M-38 Move your arm — the live angle and speed numbers move with you
- ☐ M-45 Pause and resume — the timer stops and continues correctly
- ☐ M-46 Switch a sensor off and on — it shows disconnected, then reconnects

-
- ☐ **M-51** End the session — the summary screen shows duration and devices
 - ☐ **M-54** Sync it — the badge changes to fully synced, no error
 - ☐ **W-16** The session appears in the web panel within a few minutes
-

If part B fails, stop and tell someone straight away.

Recording and sync are the heart of the product. A broken sensor flow is more urgent than anything else on this list.

4 · Mobile app — full checklist

80 checks. The Flutter app that field workers and ergonomists use to record sessions.

★ = also in the daily check · items in **Sensors**, **Calibration** and **Recording** need the kit

4.1 · Login and account M-01 → M-07

M-01	★	Open the app from cold — the splash screen passes and you land on login (logged out) or the welcome screen (logged in)
M-02	★	Log in with email and password — you reach the welcome screen
M-03		Log in with the wrong password, and with an email that doesn't exist — a clear message in your language, no crash, no raw error code
M-04		Log in with the email link — the email arrives, tapping the link opens the app and logs you in
M-05		Reset your password end to end — email arrives, new password is accepted, you can log in with it
M-06		Open an old or already-used reset link — the "link expired" screen appears, not an error
M-07		Log out, then log in as a different user — none of the previous user's sessions, workers or settings are still visible

4.2 · First launch and organisation M-08 → M-12

M-08		Install fresh and open — the onboarding screens appear and can be completed or skipped
M-09		Log in as a user who belongs to two organisations — you are asked which one to use
M-10		Log in as a user in one organisation only — no question, straight through
M-11		Switch organisation in settings — the worker list and session list change to the other organisation's data
M-12		Close and reopen the app after switching — you are still in the organisation you chose

4.3 · Sensors and pairing M-13 → M-23 · needs the kit

M-13		Open pairing with Bluetooth switched off — the app asks you to turn it on instead of showing an empty list
M-14		Deny the Bluetooth or location permission when asked — a clear explanation, and a way to get to the phone settings; no crash
M-15	★	Start a scan with sensors switched on nearby — they appear in the list with a name and signal strength
M-16	★	Assign a sensor to a limb — it connects and shows its serial number
M-17		Try to assign the same sensor to a second limb — blocked, with a message
M-18		Pair all seven limb types: right arm, left arm, trunk, head, hand, forearm, chest strap — each one connects
M-19		Connect five or more sensors at once — all stay connected, the app stays responsive
M-20		Switch a sensor off, or walk out of range, during pairing — it shows as disconnected within a few seconds; the app doesn't hang on a spinner
M-21	★	Look at each connected sensor — a battery percentage is shown and it looks believable
M-22		Look at each connected sensor — a firmware version is shown
M-23		Leave the pairing screen and come back — the sensors are still connected and still assigned to the same limbs

4.4 · Calibration M-24 → M-30 · needs the kit

M-24	★	Run a full calibration — it asks for each connected limb in turn and finishes without an error
M-25		Follow the natural-position step — it captures for about two seconds and moves on by itself
M-26		Calibrate trunk and head — they ask for a second, bent position; the arms and hand do not

M-27	Turn off two-point calibration in settings and calibrate again — the bent step is gone
M-28	Switch a sensor off in the middle of calibration — a clear error and the option to retry, not a stuck screen
M-29	Recalibrate a single limb — only that limb is redone, the others keep their calibration
M-30	Turn on lite mode and calibrate — one five-second phone calibration only, no sensor steps

4.5 · Setting up a session M-31 → M-36

M-31	Choose the session type: work task or work cycle — the next screens change accordingly
M-32	Pick the worker being measured — the list shows the organisation's workers and you can search it
M-33	Set the session conditions / workplace — your choices are saved and appear again on the summary at the end
M-34	Choose which limbs to record — only limbs that are connected and calibrated can be selected
M-35	Try to start with a sensor missing or not calibrated — start is blocked and the message says exactly what is missing
M-36	Open the work library from settings — categories and work cycles load and a selection can be made

4.6 · Recording M-37 → M-50 · needs the kit

M-37	★	Start recording — the timer starts at zero and counts up in real time
M-38	★	Raise and lower an arm — the elevation angle and speed of movement change with you, with no long delay
M-39		Bend forward and sideways — the trunk bending values change and match roughly what you're doing
M-40		Record with a chest strap connected — a heart rate in beats per minute appears and updates
M-41		Hold your arm high for a while — the indicator turns yellow then red at the thresholds, and back to green when you lower it
M-42		Leave voice feedback on — it speaks at the interval you set, in the app's language, and stops when you turn it off
M-43		Mark a task start and end during recording — both appear in the task list with the right time
M-44		Mark a break start and end — same, and it's clearly shown as a break, not a task
M-45	★	Pause, wait a minute, then resume — the timer stops while paused and continues from where it stopped, not from the wall clock
M-46	★	Switch one sensor off mid-recording, then on again — its status goes disconnected, then reconnecting, then connected, and data resumes
M-47		Put the app in the background for five minutes — recording continues and a "recording" notification is visible
M-48		Lock the phone screen for five minutes — recording continues, the timer is correct when you unlock
M-49		Receive a phone call during recording — recording survives the call
M-50		Watch the battery percentages during a longer recording — they refresh, and dropping to a low battery gives some kind of warning

4.7 · Ending a session and syncing M-51 → M-57

M-51	★	End the session — the summary shows duration, the devices used and the sync status
M-52		End a very short session, under a minute — it still saves and appears in history
M-53		Look at the session in history right after ending it — it's there with a "not synced" badge
M-54	★	Sync it — progress is shown and the badge ends up as fully synced
M-55		Start a sync with no internet — it fails with a clear message and the session is kept, not lost; you can retry later
M-56		Force-close the app in the middle of a recording, then reopen — the session is still in history and can be synced; the app doesn't get stuck thinking it's recording
M-57		Check the same session in the web panel afterwards — the duration, worker and limbs match what the phone showed

4.8 · History and reports M-58 → M-63

M-58	★	Open the session list — worker name, date, duration, sync status and limbs are shown for each
M-59		Use the filters and sorting — the list changes as expected and clearing the filter brings everything back
M-60	★	Open a session report — risk data per limb and the charts draw, with sensible colours
M-61		Open the TNO report — it loads with the static and dynamic breakdown
M-62		Add a work label to a session from history — it saves and is still there after leaving and coming back
M-63		Open a session that recorded almost nothing — an empty or "no data" state, not a crash or a blank screen

4.9 · Offline M-64 → M-69

M-64	★	Turn off wifi and mobile data — an offline indicator appears within a few seconds
------	---	---

M-65	Record a complete session while offline — it records and saves normally
M-66	Pair and calibrate while offline — both work; they don't need the internet
M-67	Open history and a cached report while offline — they open
M-68	Try to log in as a new user while offline — refused with a clear message about needing an internet connection
M-69	Turn the internet back on and sync the offline sessions — they upload and appear in the web panel

4.10 · Settings and support M-70 → M-80

M-70	★ Change a setting, force-close the app, reopen — the change is still there
M-71	Switch the app language to each of English, Swedish, German, Spanish and Dutch — every screen is translated, no English left behind, no text cut off or overlapping
M-72	Change the IMU sample rate, gyroscope range and accelerometer range — they save, and the next session records without errors
M-73	Turn on lite mode and record — it records with the phone alone, one limb only, and the session saves
M-74	Turn heart rate tracking on and off — the heart rate tile appears and disappears accordingly
M-75	Turn location tracking on and record — the permission is asked for once and location data ends up in the session
M-76	Change the voice feedback interval and the limb priority order — the next recording follows the new settings
M-77	Change the battery check interval — saved, and battery values refresh at roughly that rate
M-78	Change the session duration limit — saved; a session stops itself at the limit
M-79	Send a report from "report a problem", with an attachment — it sends, you get a confirmation, and the ticket reaches the team
M-80	Open an old app version against the current backend — the force-update screen appears instead of letting you use a broken version

5 · Client panel — full checklist

92 checks. The web app ergonomists and org admins use to analyse the recorded data.

★ = also in the daily check

5.1 · Login, signup and invitations W-01 → W-11

W-01	★	Open the login page — it loads fully, logo and fields in place, nothing shifting around
W-02	★	Log in with email and password — you land on the home page
W-03		Log in with the email link — the email arrives, the link logs you in, and it can't be reused afterwards
W-04		Try a wrong password, an unknown email and an empty form — a clear message each time, no technical error text, no crash
W-05		Reset a password end to end — email arrives, the new password works, the old one doesn't
W-06		Log in with a worker account — refused with "Workers cannot access this application" and signed out
W-07		Register a new organisation from the public form — required fields are validated, the organisation and its admin are created, and you can log in
W-08		Invite someone to the organisation — the email arrives, the link opens the invitation page, accepting adds them with the role you chose
W-09		Open an invitation older than seven days, and one already accepted — a proper "expired" or "already used" message, not an error page
W-10		Refresh the page while logged in — you stay logged in and on the same page
W-11	★	Log out, then press the browser back button — you stay on the login page; the dashboard doesn't reappear

5.2 · Home W-12 → W-15

W-12	★	Open home — user numbers, measurement numbers and licence information all load, no empty or broken cards
W-13		Change the date range — the numbers change; a range with no data shows zero, not a broken card
W-14		Compare the measurement count on home with the measurements list — they agree
W-15		Check the licence card — expiry date and usage against the limits are shown and look right for that organisation

5.3 · Measurements list W-16 → W-27

W-16	★	Open the measurements list — rows load with worker, date, duration, status and tags
W-17		Switch between active, finished and archived — each shows the right sessions and nothing leaks between them
W-18	★	Search a worker's name — the list filters; a nonsense search gives a clean empty state
W-19		Filter by limb and by status — results match the filter, and clearing it restores the full list
W-20		Sort by each column, both directions — the order is actually correct, including dates and durations
W-21		Go to page two, change the page size, then change a filter — the page resets sensibly instead of showing an empty page
W-22		Select several rows — the bulk action bar appears with the right count
W-23		Archive several at once — they move to archived; unarchiving brings them back to finished
W-24		Delete a measurement — you are asked to confirm, and after confirming it's really gone, also after a refresh
W-25		Cancel a delete — nothing is deleted
W-26		Import a measurement file — a valid file imports; a wrong or corrupt file gives a readable error, not a crash
W-27		Look at an organisation with no measurements at all — a friendly empty state that explains what to do, not a blank table

5.4 · Measurement detail W-28 → W-40

W-28	★	Open a finished measurement — worker, duration, date, status and the devices used are shown, and the charts draw
W-29		Use the posture chart: zoom, scroll, page through a long session — it stays smooth and the axis labels stay correct
W-30		Hover a point on the chart — the tooltip shows a value and, where relevant, the logged event at that time
W-31		Check the speed-of-movement chart — it draws and its values are in a believable range
W-32		Check the risk-zone donuts — the green, yellow and red slices add up to 100% and match the colours used elsewhere
W-33		Check the wrist distance zones — under 30 cm, 30–50 cm and over 50 cm are shown and add up
W-34		Open a session recorded with a chest strap, and one without — the heart rate section shows data in the first and hides or says "no data" in the second
W-35		Check temperature per limb — a value per recorded limb, nothing wildly out of range
W-36		Check the TNO section — the static and dynamic breakdown per angle range loads
W-37		Open a session where tasks and breaks were marked on the phone — the task-by-task breakdown shows them with the right names and times
W-38		Add a note to the session log — it saves, shows who added it and when, and survives a refresh
W-39		Press recalculate — a progress state is shown and the numbers come back updated, not blank
W-40		Go back to the list from a measurement — your filters, tab and page are still applied

5.5 · Comparing measurements W-41 → W-44

W-41	Select several measurements and open the comparison — all of them appear side by side
W-42	Go through the comparison tabs: results table, TNO, heart rate, temperature — each loads, and a tab with no data for one session says so instead of showing nothing
W-43	Export the comparison to Excel — the file downloads, opens, and the numbers match the screen
W-44	Compare sessions that recorded different limbs, and try to compare just one — handled sensibly with a message, not a broken page

5.6 · Reports, exports and AI W-45 → W-51

W-45	Export one measurement to Excel — it downloads, opens, and the values match the detail page
W-46	Export the raw data — the file downloads and isn't empty
W-47	Export a Word report and switch the section toggles on and off — the document contains exactly the sections you ticked, and the charts and text are readable
W-48	Create a report template, use it, edit it, delete it — each step works and the template is applied when exporting
W-49	Generate the AI analysis — a progress state, then real text in the language you chose, saved so it shows again after a refresh instead of regenerating
W-50	Generate the AI analysis on a session with almost no data — it fails or explains itself clearly; it doesn't spin forever
W-51	Download an assessment result as PDF — the file opens and the layout isn't cut off

5.7 · Assessments W-52 → W-63

W-52	★ Open the assessments list — it loads with method, status, worker and date
W-53	Filter by method and by status — results match
W-54	Create a new assessment from the modal — it's created and opens on the first step
W-55	Fill a RAMP assessment through all seven steps — every step saves, going back keeps your answers, and the body diagrams respond correctly
W-56	★ Open a completed assessment result — the score, the colour coding and the breakdown are shown
W-57	Generate a RAMP from a session and continue it — the suggested values are filled in, can be changed, and saving keeps your changes
W-58	Fill a RULA: left side, right side, neck/trunk/legs — each section scores and the final score matches the method's own table
W-59	Fill a REBA the same way — sections score and the final score is correct
W-60	Generate a MEC from a session — it processes and the results page shows values, not an empty page
W-61	Leave an assessment half-filled and come back later — it's marked in progress and resumes exactly where you left off
W-62	Open the multi-compare view for each method — several assessments side by side, with correct scores
W-63	Delete assessments in bulk, and export to AVIX — delete asks for confirmation and works; the AVIX file downloads

5.8 · Workers W-64 → W-70

W-64	★ Open the workers list — it loads, search and filters work
W-65	Add a worker — required fields are validated, a bad email is rejected, and the worker appears in the list
W-66	Open a worker and fill the full profile: weight, resting heart rate, gender, dominant arm, date of birth, comment — all save and are still right after a refresh
W-67	Enter impossible values — a negative weight, a birth date in the future — rejected with a clear message

W-68	Assign a consultant to a worker — it saves and shows on the worker
W-69	Deactivate a worker — they leave the active list but their past measurements are still there and still open
W-70	Add workers up to the organisation's limit — going over gives a clear message about the limit

5.9 · Team W-71 → W-76

W-71	★ Open Team as an org admin — the member list loads with names, roles and status
W-72	Log in as an ergonomist — Team is not in the menu, and typing its address directly doesn't get you in
W-73	Invite a team member with a role — the invitation is sent and shows as pending
W-74	Change a member's role — after they log in again, what they can see and do actually matches the new role
W-75	Deactivate a member — they can no longer log in, and their existing data stays
W-76	Add admins up to the organisation's admin limit — going over gives a clear message

5.10 · Work library W-77 → W-82

W-77	★ Open the work library — the factory → line → workstation → task tree loads and expands
W-78	Create, rename and delete an item at each level — each works, and deleting a level with children warns you first
W-79	Import a work cycle from Excel and from an AVIX file — a good file imports and the tree updates; a bad file gives a readable error
W-80	Create a category and add labels to it, including a private one and a favourite — all save and appear in the mobile app after a refresh
W-81	Try to delete a label that is used by a measurement — you are warned, or the measurement keeps working afterwards; nothing silently breaks
W-82	Check that one organisation's work library is not visible to another organisation — it isn't, including by putting the other organisation's id in the address bar

5.11 · Settings and profile W-83 → W-87

W-83	Edit your profile: name, personal number, AI consent — saves, and the name updates in the top bar straight away
W-84	Edit the organisation details and upload a logo — the logo appears in the app and in exported reports; an oversized or wrong-format file is rejected clearly
W-85	★ Switch the interface language through all five — everything translates, nothing overflows its box, and the choice survives a refresh
W-86	Switch the RAMP limit display between time and percentage — the results view actually changes
W-87	Open the privacy policy and data deletion pages — they load, including when logged out

5.12 · Notifications W-88 → W-92

W-88	★ Open the notification bell — the list loads and the unread count matches it
W-89	Finish and sync a session, then wait — a notification appears when the processing is done
W-90	Generate an assessment — a notification appears for it too
W-91	Click a notification — it opens the measurement or assessment it refers to, not a dead page
W-92	Mark as read and delete — the count drops correctly and the change survives a refresh

6 · Admin panel — full checklist

9 checks. Superadmin only — organisations, users across all organisations, devices and firmware.

Check before you start.

The admin panel currently talks to a backend running on a developer's own machine, so it can't be tested on a normal URL yet. Ask the team how to run it — or whether to skip this section for now.

A-01	Log in as superadmin, then try with an org admin and an ergonomist account — only the superadmin gets in; the others are refused clearly
A-02	Open the organisations list and use the filters: country, active, archived, licence expiry — results match, search and sorting work
A-03	Create an organisation with a logo — it's created, appears in the list, and can be logged into
A-04	Edit an organisation's limits and licence expiry — saved, and the client panel enforces the new limits
A-05	Archive and unarchive organisations in bulk — they move between the lists, and users of an archived organisation are handled as expected
A-06	Open the users list and filter by organisation and role — results match; a user in two organisations shows both
A-07	Add a user to an organisation, then deactivate them — both take effect on their next login
A-08	Open the devices list — serial number, firmware, organisation and assigned worker are shown; search works
A-09	Add a firmware version, edit it, mark it as current — it saves, and the mobile app offers that version as an update

7 · Cross-cutting checks

13 checks. Not tied to one feature — run these once per release, across the whole product. This is where most of the embarrassing bugs hide.

X-01	Walk the main screens in each of English, Swedish, German, Spanish and Dutch, on web and mobile — no untranslated text, nothing cut off, nothing overlapping, dates and numbers formatted for that language
X-02	Repeat the main flows as org admin, ergonomist and worker — each role sees exactly what it should, and no more
X-03	While logged into one organisation, put another organisation's measurement or worker id in the address bar — access denied, not someone else's data
X-04	Use the web app at 1366, 1920 and tablet width — nothing overlaps, tables scroll instead of breaking the page, menus still reachable
X-05	Run the main web flows in Chrome, Edge, Safari and Firefox — they behave the same; note the browser if one differs
X-06	Throttle the network to slow, then reload pages and submit forms — loading states appear; nothing shows a blank page or a raw error
X-07	Turn the network off mid-action on the web — a clear message and a way to retry; the app doesn't get stuck
X-08	Refresh in the middle of a flow, use the browser back button, and open a deep link in a new tab — you end up somewhere sensible, still logged in, with nothing half-saved
X-09	Leave the app open overnight, then use it — it either still works or asks you to log in again; it never silently fails on every click
X-10	Double-click every submit and save button — nothing is created twice
X-11	Put very long text, emoji and characters like <code>< > & ' "</code> into every name and comment field — saved and displayed correctly, no broken layout, no error

X-12	★	Keep the browser console open while you test — no red errors on normal use
X-13		Open a very long session, and a worker with a hundred measurements — the pages still load in a reasonable time and the charts stay usable

8 · Known and already reported — do not file these

Read this before your first run, and check back before filing anything that looks odd in these areas. These are either unfinished on purpose or already known to the team.

Unfinished on purpose — they'll be built later

Where	What you'll see
Mobile · vibration panel	The time display and the limb toggle aren't built. The panel looks half-empty. Not a bug.
Mobile · firmware update	The dialog offers an update, but the button doesn't start it. Known.
Mobile · sensor list buttons	Pair, unpair and disconnect in the settings sensor list do nothing when tapped. Known.
Mobile · work cycle auto-advance	The setting exists but the app doesn't actually move to the next task by itself.
Mobile · failed syncs	There is no automatic retry. If a sync fails, the user has to press sync again. That's the current design, not a bug.
Web · real-time updates	The web panel doesn't update by itself — you have to refresh to see a new measurement. Expected for now.
Admin panel	Points at a local backend, so it doesn't work on a deployed address. Already on the team's list.

Looks wrong, is intentional

The head and trunk "0° to 10°" posture band.

It actually covers −5° to 10° — it includes a small amount of backward bending. This was decided deliberately, so a value of −3° landing in the "0–10°" band is correct behaviour. Don't report it.

When you're not sure whether something is a bug.

Ask. It's much better to ask a quick question than to either stay silent about a real bug or file a ticket for something that was designed that way. Both cost the team time — asking costs almost nothing.

Keeping this section honest

When one of these gets built or fixed, it should be removed from this page and the matching check should go back into the normal list. Tell us when you notice one is done — you'll usually see it before we do.

And the one thing worth repeating.

Anything about recording, sensors or sync is more serious than anything else in this document. If a measurement can't be recorded, or recorded data doesn't arrive in the web panel, that's a critical bug — report it immediately, don't wait until the end of your run.